

Magnetic Field Sensor

(Order Code MG-BTA)



The Vernier Magnetic Field Sensor measures a vector component of the magnetic field near the sensor tip. The tip can be adjusted, allowing the user to measure fields that are parallel or perpendicular to the long axis of the sensor. The Magnetic Field Sensor can be used for a variety of interesting experiments involving magnetic fields.

- Measure and study the Earth's magnetic field.
- Determine the direction of magnetic north.
- Study the magnetic field near a permanent magnet.
- Measure the field near a current-carrying wire.
- Measure the field at the opening of a solenoid.

Note: Vernier products are designed for educational use. Our products are not designed nor are they recommended for any industrial, medical, or commercial process such as life support, patient diagnosis, control of a manufacturing process, or industrial testing of any kind.

Compatible Software and Interfaces

See www.vernier.com/manuals/mg-bta for a list of interfaces and software compatible with the Magnetic Field Sensor.

Getting Started

1. Connect the sensor to the interface (LabQuest Mini, LabQuest 2, etc.).
2. Start the appropriate data-collection software (Logger Pro, Logger Lite, LabQuest App) if not already running, and choose New from File menu.

The software will identify the sensor and load a default data-collection setup. You are now ready to collect data.

If you are collecting data using a Chromebook™, mobile device such as iPad® or Android™ tablet, or a Vernier wireless sensor or interface, please see the following link for up-to-date connection information:

www.vernier.com/start/mg-bta

Using the Sensor

Connect the sensor following the steps in the Getting Started section of this user manual.

Use the switch on the sensor shaft to select an appropriate range.

- The 6.4 mT range is used to measure relatively strong magnetic fields around permanent magnets and electromagnets.
- The 0.32 mT range is used mainly to measure the magnetic field of the Earth and very weak fields. It can be used for other magnets, but the sensor must remain in one position so that the reading is not affected by the background field of the Earth.

Videos

View videos related to this product at www.vernier.com/mg-bta

Calibration

You should not have to perform a new calibration when using the Magnetic Field Sensor. We have set the sensor to match our stored calibration before shipping it.

It is not practical to calibrate the Magnetic Field Sensor without reference to a known source of magnetic field. It is useful, however, to zero the Magnetic Field Sensor. Position the sensor and zero it using your data-collection software. Move the magnetic field source, and not the sensor, to explore the spatial variations of the field.

Moving the sensor will upset the zero since the background magnetic field in your lab probably varies with position. For experiments measuring the spatial variation of a magnetic field, it is better to zero the sensor and then move the source to various positions.

Specifications

13-bit resolution	± 0.32 mT range: 0.0001 mT ± 6.4 mT range: 0.002 mT
12-bit resolution	± 0.32 mT range: 0.0002 mT ± 6.4 mT range: 0.004 mT
10-bit resolution	± 0.32 mT range: 0.0008 mT ± 6.4 mT range: 0.016 mT
Stored calibration value (± 0.32 mT range in millitesla)	slope: 0.160 mT/V intercept: -0.320 mT
Stored calibration value (± 6.4 mT range in millitesla)	slope: 3.225 mT/V intercept: -8.063 mT
Stored calibration value (± 0.32 mT range in gauss)	slope: 1.6 gauss/V intercept: -3.2 gauss
Stored calibration value (± 6.4 mT range in gauss)	slope: 32.25 gauss/V intercept: -80.625 gauss

How the Sensor Works

The sensor uses a Hall-effect transducer. It produces a voltage that is linear with magnetic field. The sensor measures the component of the magnetic field that is perpendicular to the white dot on the end of the sensor tip. The reading is positive when the white dot on the sensor points toward a magnetic south pole.



The switch on the sensor shaft is used to select the range. On the 6.4 mT range, each volt measured by the transducer represents 32 gauss (3.2×10^{-3} tesla). The range of the sensor is ± 64 gauss or $\pm 6.4 \times 10^{-3}$ tesla. On the 0.3 mT range, each volt measured represents 1.6 gauss (1.6×10^{-4} tesla). The range of the sensor is ± 3.2 gauss or $\pm 3.2 \times 10^{-4}$ tesla.

If the sensor tube is held vertically with the tip horizontal, and rotated until the maximum voltage is found, the tip with the white dot will point to magnetic north. The magnetic inclination in your area can be found by holding the tube so that the white dot is facing north, and rotating the sensor end of the tube down until the voltage reaches a maximum. The angle of the tip from the vertical position is the magnetic inclination. Note that the north pole of a freely suspended magnet points north, since the magnetic pole of the Earth in the northern hemisphere is a south magnetic pole.



Troubleshooting

If you are getting unexpected or unusual readings from the Magnetic Field Sensor, first confirm that the range setting is appropriate for the experiment. The ± 6.4 mT range is used to measure relatively strong magnetic fields around permanent magnets and electromagnets; the ± 0.32 mT range is used to measure the magnetic field of the Earth and very weak fields. If you are using the ± 0.32 mT range for investigating permanent magnets, make sure that the sensor remains in one position so that the reading is not affected by the background field of the Earth.


For other troubleshooting tips and FAQs, see www.vernier.com/til/1420

Repair Information

If you have watched the related product video(s), followed the troubleshooting steps, and are still having trouble with your Magnetic Field Sensor, contact Vernier Technical Support at support@vernier.com or call 888-837-6437. Support specialists will work with you to determine if the unit needs to be sent in for repair. At that time, a Return Merchandise Authorization (RMA) number will be issued and instructions will be communicated on how to return the unit for repair.

Warranty

Vernier warrants this product to be free from defects in materials and workmanship for a period of five years from the date of shipment to the customer. This warranty does not cover damage to the product caused by abuse or improper use. This warranty covers educational institutions only.



MEASURE. ANALYZE. LEARN.™

Vernier Software & Technology

13979 SW Millikan Way • Beaverton, OR 97005-2886

Toll Free (888) 837-6437 • (503) 277-2299 • FAX (503) 277-2440

info@vernier.com • www.vernier.com

Rev. 2/8/16

Logger Pro, Logger Lite, Vernier LabQuest 2, LabQuest Mini, and other marks shown are our trademarks or registered trademarks in the United States.

All other marks not owned by us that appear herein are the property of their respective owners, who may or may not be affiliated with, connected to, or sponsored by us.